

Field Devices

Field Devices for the *XAtlas* server

The Field Devices allow creating a physical interface between the XAtlas server (D or E version) and the environment to control, in a manner that is both flexible and modular.

The **Field Devices** of the XAtlas server allow detecting states, identifying users and controlling equipment.

A wide range of devices can be selected **in order to meet various needs**:

- ✓ **application** (only access control, access control and time and attendance, intrusion detection systems, etc.);
- ✓ target **environment** (indoor or outdoor);
- ✓ **identification technologies** (magnetic cards, proximity cards, smart cards and biometric measurements);
- ✓ **detection technologies** (volumetric or perimeter sensors).

The Field Devices connect via a **RS485 data bus** to Field Processors (FM, XPoint touch, Xpoint Glass) on which they depend for their online operation.

Some FD models are **also available in Ethernet version** thus eliminating the need for RS485 cables.

It is also **possible to connect third party** peripherals to provide the best solution for any requirement of Time and Attendance, Access Control or Intrusion Detection.

AXESS TMC

a brand of Zucchetti Axess S.p.A



FD-RFID4K – Card reader with integrated keypad – IP55
 RS485 module with MIFARE reader and 12-key membrane keypad
 Allows only PIN, only badge, badge+PIN transactions



FD X1 – FD X2 Readers with graphic display, I/O and keypad – IP55
 A RF card reader, graphic display, keypad, 2 digital inputs and one relay all in one device.
Available in 2 versions: With 10-key numeric keypad for transactions with PIN and 6 function keys (FD-X2) or with only 6 function keys (FD-X1).
 Each version is available with **different proximity card reader technologies** integrated: MIFARE®; HID® 125Khz; EM4102 (125 KHz Unique); Legic® Advant. HID® I-Class. Possibility to integrate a magnetic or biometric barcode reader (FingerBOX with capacitive/optical sensor) fixed to the bottom of the device with a special bracket.



FingerBOX – Optional biometric reader for FD X1 or FD X2
 Stores up to 9500 templates.
Operating modes: - verification:
 Allows the enrolment of fingerprints which are stored in the XAtlas software and then distributed selectively to other biometric readers.
 Available with optical or capacitive sensor



XFinger – Biometric reader with optical sensor, buzzer and LEDs – IP65
 Available with integrated MIFARE reader or without reader
 Stores up to 9500 templates received from XAtlas (local enrolment is not possible)
 Operating modes:
 Identification: finger only (1:N)
 Verification: card+finger (1:1) even with template stored on badge
 Card only
 Also suitable for outdoor use – Optical Sensor



FD AX BIO / FD AX RF – Built-in MIFARE reader with button, buzzer, circular LED, relay
 Available with only MIFARE reader (FD AX RF) or also with integrated optical biometric reader with 9500 templates (FD AX BIO).
 The operating modes of the biometric version are the same as XFinger with MIFARE reader. Also in this case, enrolment is not possible.
 It can pilot a bell. Also suitable for outdoor use.



FD-DA0x – Module with 8 inputs and 4 relays
 Sends the state of the sensors to the XAtlas software in real time.
 It can control electric locks, turnstiles, lights, alarms, sirens, etc.
 The function of each input or relay can be assigned independently by XAtlas.



FD GA03 – FD-DO03 – FE GA03 – FE-DO03 – Modules with inputs, relays and interface for readers – RS485/Ethernet version
FD-GA03: 8 balanced inputs, 4 mechanical relays, 2 connectors for readers with LED. RS485 connection
FD-DO03: 2 balanced inputs, 2 mechanical relays, 1 connector for reader with LED. RS485 connection
 The homologous FE versions have the same I/O devices as the FD version, but with an Ethernet connection instead of a RS485 connection. Other FD devices can be connected to the RS485 port of the FE versions, thus reducing or eliminating the 485 cables.



FE-GA04 FE-DO04 –Modules and Gateways for Aperio Wireless Online Locks
FE GO04: 8 balanced inputs, 4 mechanical relays, 2 connectors for readers with LED.
FE DO04: 2 balanced inputs, 2 mechanical relays, 1 connector for reader with LED.
 Ethernet connection to the XAtlas system
 An Aperio HUB can be connected to the RS485 port for piloting up to 8 online wireless locks.



FD-DF04 FE-DF04 – Modules for systems with Aperio Wireless Offline Locks
 2 balanced inputs, 2 mechanical relays, 1 connector for reader with LED.
FD-DF04: RS485 connection
FE-DF04: Ethernet connection
 Downloads transactions from the memory of the MIFARE cards. Resets the memory of the badge and sends transactions made on the Wireless Locks to the server



FD-WB01 (FD-NeoMAX)
 2 inputs, 2 relays that can be assigned independently by the XAtlas server
 1 connector for reader with Wiegand or Clock&Data interface
 RS485 connection to the Field Processor.